



NOTES:

1. CHIP OUT EXISTING CONCRETE DOWN TO EXISTING STEEL LINER
2. ABRASIVE BLAST STEEL LINER TO WHITE METAL.
3. INSTALL THE MBrace® EG 900 SYSTEM
4. BROADCAST SILICA SAND TO REFUSAL IN THE FINAL LAYER OF MBrace SATURANT
5. PATCH THE AREA WITH EMACO® S-88 REPAIR MORTAR.

DETAIL AT TERMINATION OF CARBON FIBER LINER



N.T.S.

CURRENT ISSUE DATE: 07 AUG 2006	DRAWN BY: WJG
DATE CREATED: 03 MAY 2006	CHECKED BY: WJG
DRAWING NO: B-1031	

STANDARD DETAIL

MBrace® FRP Strengthening System
STRUCTURAL LINER FOR PCC PIPE

BASF
The Chemical Company

BASF Building Systems
889 Valley Park Drive
Shakopee, MN 55379

Customer Service: 800-443-9517
Technical Service: 800-243-6739

www.basfbuildingsystems.com

MBrace®

Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of BASF Building Systems, LLC ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whole or part, is strictly prohibited, except for the express purpose for which it has been furnished, without prior written consent of Company. All Materials contained herein are provided by Company for information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technical or other advice by Company, whether verbal or written, concerning products, or the use of products in specific situations ("Advice") is given by Company and is used at the Users own risk.